


DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

Z1+Z2+Z3+Z4+Z5+Z6

Cod.: 090-DIA-10314  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

Z1+Z2+Z3+Z4

Cod.: 090-DIA-10315  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

Z1+Z2+Z3

Cod.: 090-DIA-10316  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

Z1+Z2

Cod.: 090-DIA-10317  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




MC 400

NZ

Cod.: 090-DIA-10318  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 200 Z1+Z2+Z3+Z4+Z5+Z6

Cod.: 090-DIA-10319  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 200 Z1+Z2+Z3+Z4

Cod.: 090-DIA-10320  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



## MC 400


ST 200 Z1+Z2+Z3

Cod.: 090-DIA-10321

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




MC 400

ST 200 Z1+Z2

Cod.: 090-DIA-10322  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 200 NZ

Cod.: 090-DIA-10323  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 300 Z1+Z2+Z3+Z4+Z5+Z6

Cod.: 090-DIA-10324  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 300 Z1+Z2+Z3+Z4

Cod.: 090-DIA-10325  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 300 Z1+Z2+Z3

Cod.: 090-DIA-10326  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




MC 400

ST 300 Z1+Z2

Cod.: 090-DIA-10327  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 300 NZ

Cod.: 090-DIA-10328  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




MC 400

Z1+Z2+Z3+Z4+Z5+Z6

Cod.: 090-DIA-10329  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


Z1+Z2+Z3+Z4

Cod.: 090-DIA-10330  
 Scala: 1:100



DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




MC 400

Z1+Z2

Cod.: 090-DIA-10332  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




MC 400

NZ

Cod.: 090-DIA-103133  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 200 Z1+Z2+Z3+Z4+Z5+Z6

Cod.: 090-DIA-10334  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 200 Z1+Z2+Z3+Z4

Cod.: 090-DIA-10335  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 200 Z1+Z2+Z3

Cod.: 090-DIA-10336  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 200 Z1+Z2

Cod.: 090-DIA-10337  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




MC 400

ST 200 NZ

Cod.: 090-DIA-10338  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 300 Z1+Z2+Z3+Z4+Z5+Z6

Cod.: 090-DIA-10339  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 300 Z1+Z2+Z3+Z4

Cod.: 090-DIA-10340  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 300 Z1+Z2+Z3

Cod.: 090-DIA-10341  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 300 Z1+Z2

Cod.: 090-DIA-10342  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



## MC 400

ST 300 NZ


Cod.: 090-DIA-10343  
 Scala: 1:100





DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

Z1+Z2+Z3

Cod.: 090-DIA-11972  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


Z1+Z2

Cod.: 090-DIA-11973

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



## MC 400


NZ

Cod.: 090-DIA-11974

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



## MC 400


ST 200 Z1+Z2+Z3+Z4+Z5+Z6

Cod.: 090-DIA-11975

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



## MC 400

ST 200 Z1+Z2+Z3+Z4


Cod.: 090-DIA-11976

Scala: 1:100



DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



## MC 400


ST 200 Z1+Z2

Cod.: 090-DIA-11978

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



## MC 400


ST 200 NZ

Cod.: 090-DIA-11979

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



## MC 400


ST 300 Z1+Z2+Z3+Z4+Z5+Z6

Cod.: 090-DIA-11980

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



## MC 400


ST 300 Z1+Z2+Z3+Z4

Cod.: 090-DIA-11981

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


ST 300 Z1+Z2+Z3

Cod.: 090-DIA-11982

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



## MC 400


ST 300 Z1+Z2

Cod.: 090-DIA-11983

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


ST 300 NZ

Cod.: 090-DIA-11984

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




  
 MAX 6t N.2 rope    MAX 3.5t N.1 rope


## MC 400

Z1+Z2+Z3+Z4+Z5+Z6

Cod.: 090-DIA-11985  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


Z1+Z2+Z3+Z4

Cod.: 090-DIA-11986

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


Z1+Z2+Z3

Cod.: 090-DIA-11987

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


Z1+Z2

Cod.: 090-DIA-11988

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


NZ

Cod.: 090-DIA-11989

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 200 Z1+Z2+Z3+Z4+Z5+Z6

Cod.: 090-DIA-11990  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



## MC 400


ST 200 Z1+Z2+Z3+Z4

Cod.: 090-DIA-11991

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


ST 200 Z1+Z2+Z3

Cod.: 090-DIA-11992

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


ST 200 Z1+Z2

Cod.: 090-DIA-11993

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




MC 400

ST 200 NZ

Cod.: 090-DIA-11994  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


ST 300 Z1+Z2+Z3+Z4+Z5+Z6

Cod.: 090-DIA-11995

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


ST 300 Z1+Z2+Z3+Z4

Cod.: 090-DIA-11996

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400


ST 300 Z1+Z2+Z3

Cod.: 090-DIA-11997

Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG




## MC 400

ST 300 Z1+Z2

Cod.: 090-DIA-11998  
 Scala: 1:100

DIAGRAMMA DELLE PORTATE (t)  
 CAPACITY DIAGRAM (t)  
 TRAGLASTDIAGRAMM (t)  
 LASTENDIAGRAM (t)  
 TABLEAU DES CHARGES (t)  
 DIAGRAMA DE LAS CARGAS (t)

# JMG



MC 400

ST 300 NZ

Cod.: 090-DIA-11999  
 Scala: 1:100